



# Operating manual: LBD-GLC-ESZ-OP **Photoelectric Light Barrier**







IECEx BVS 14.0108X



Ex db [op is Ga] IIC T6 Gb Ex tb [op is Da] IIIC T100°C Db

- Robust light barrier for industrial applications
  Alignment aid by 3-color LED at the rearside of the receiver

Type Technical Data	LBD-GLC-ESZ-OP			
Designation	Emitter: LB*-*A/B/C/D/E/F/OZ-***-OP / Receiver: LB*-*L/M/NC-***-OP			
Gas Ex protection designation	II 2(1)G Ex db [op is Ga] IIC T6 Gb			
Dust Ex protection designation	II 2(1)D Ex tb [op is Da] IIIC T100°C Db			
For use in Ex Zones	Zones (0), 1, 2, (20), 21, 22			
Light Source	Infrared 870nm			
Measuring range	120m			
Min. recognizable object size	12mm (Avoid deflections on reflective surfaces)			
Optical aperture angle	approx. 15°			
Pollution degree	4, according to EN 60664-1:2007			
Supply voltage, Ue	24VDC ± 10%			
Absolute maximum supply voltage, Um	30VDC			
Current consumption				
Maximum power dissipation	40mA 1.12W			
Power up delay time				
	500ms			
Housing	M18			
Enclosure rating	IP67			
Ambient working temperature range, T <sub>amb</sub>	-20°C up to +50°C			
Storage temperature range	-20°C up to +70°C			
Relative humidity	15% 90%, noncondensing			
Connection cable	PVC cable shielded black 4xAWG24, Length: 20m			
Accessories	Included		Option	al
	4x Nuts M18 (or 2x Clamps on request)			
Options	LBx-*M*-***-OP Inverted output funct LBx-*M*-***-OP With pollution indicate			
Function and LED Indication	Light beam interrupted LED shows red  Light beam not interrupted LED shows yellow or green			
Output circuitry	0 +24VDC         PNP=OFF         R 15 Ω         OUT         0 OV     +24VDC  PNP=ON  R 15 Ω  OUT  OV  OV			
Alignment and Controlling by LED Display (At the rearside of the receiver).	LED color		Meaning	
	red		light beam interrupted or not aligned	
	yellow		polluted lenses or badly aligned	
			light beam free and well aligned	
	green light beam free and well aligned			
EX related markings	C€ 1258  Typ: LBD-GLC-ESZ-OP  Gas: I 2(1)G Ex db [op is Ga] IIC T6 Gb  ATEX:  IECEx:  Tamb:  Manufacturer with Address  Electrical data according to table  Dust: I 2(1)D Ex tb [op is Da] IIIC T100°C Db  BVS 10 ATEX E 130 X  IECEx BVS 14.0108X  -20°C up to +50°C  Number 5 to 8 of the Serial Number (Year / CW)			
Wiring Diagram	LB*-* <b>L/N</b> *-***-OP	LB*-* <b>M</b> *-***-OP	LB*-* <b>B/C/D/E/O</b> *- ***-OP	LB*-* <b>A/F</b> *-***-OP
	brown 24VDC	24VDC	24VDC	24VDC
	black 0V	0V	0V	0V
	red OUT	OUT	-	DI
	orange –	VA VA	_	_

# Operating Manual / EC-/EU-declaration of conformity

# Installation prescriptions for Ex hazardous locations

General prescriptions for all Ex devices:

It is necessary to take into consideration the valid international and national rules and regulations (EN 60079-14). The maximum input voltage Um = 30VDC must not be exceeded. The local equipotential bonding have to be done. The protective earth (PE) terminal is solid connected with the housing. The cable have to be protected against damages. The cable with termination fittings, or in cable tray systems and installed in a manner to avoid tensile stress at the termination fittings. To connect cables inside hazardous locations only use certificated Ex housings. All cable terminals must be connected outside hazardous locations. Use only original manufactured fibre optics and additional optical lenses, other additional optical lenses are not allowed in hazardous locations.

LBD-GLC-ESZ-OP: Applicable in Ex zones 1, 2, 21 and 22. The limited optical radiation can operate into hazardous locations (0) and (20) through a certificated viewing glass

### General mounting prescriptions

Do not exceed the maximum ratings. The electrical connections must be exactly as shown in the connection diagram. The cable shield must be connected short. The cable shield should be connected to the protection earth, large-surfaced. Connection cables must not be installed parallel to high voltage cables. During electrical installation, the power must be disconnected from the device.

The light barriers can be used e.g. for the detection of objects (bottles, cans, etc.) on a conveyor belt. This light barrier consists of a transmitter and a receiver. transmitter and the receiver are correctly positioned and the light beam from the transmitter is not interrupted by an object, the receiver will show green on the indicator LED and the output is switched on. If the light beam is interrupted by an object, then the indicator LED shows red and the output is switched off.

# Arrangement of light barriers, types LB\*-\*\*\*-A/B/C/D\*\*-OP

If several light barriers are installed close to another, it is necessary to use light barriers with different emitter frequencies (A to D). Light barriers with different emitter frequencies have no influence on each other. Precaution: If a receiver is influenced by other emitters of another type, TOFF may increase from 30ms up to 400ms. High speed light barriers and high temperature light barriers cannot be combined with frequency light barriers A to D. To avoid interference effects, all emitters should be installed at the same side and all receivers at the other side. For indoor applications the background should be protected against clutters, by using light absorbing materials.

# Arrangement of light barriers, types LB\*-\*\*\*-E\*\*-OP

If several light barriers are installed close to another, it is necessary to use light barrier emitters with the optional disable input. By using the disable input DI, each emitter can be controlled in a short reaction time. If only one emitter is activated in the same time, a mutual influence is precluded.

DI = 0V or not connected emitter enabled DI = High (24VDC) emitter disabled

The Disable Input DI must be activated for >= 15ms. The DI input is PNP compatible. The Emitter-Disable-Input DI can also be used for testing the associated receiver. By a short-time shut-off of the emitter, the switching off of the receiver output and with it the correct function of

Alignment of the Light Barrier
1. Align transmitter with receiver.
2. The 3-color status display at the back of the receiver enables optimum alignment of the receiver. Align receiver so that the receiver LED shows "green". Look for the center of the green area. If the LED lights up yellow, the light barrier is not optimally aligned or the lenses

# Maintenance

No special maintenance is required. If the lenses becomes dirty, they should be cleaned with a non-aggressive solvents. Equipment must only be repaired by the manufacturer.

### General safety instructions

The LBD-GLC-ESZ-OP light barriers must not be used for accident protection. In the case of a malfunction, the output can have any state. During installation, operation and maintenance, it is mandatory to meet the relevant EU and national regulations and directives, especially with regard to explosion protection: EN 60079-14, Directives 1999/92/EC and 2014/34/EU.

### General notes, disposal

We reserve the right to modify our products. Our products are designed in such a way, that it has the least possible adverse effect on the environment. It neither emits or contains any damaging or siliconized substances and use a minimum of energy and resources. No longer usable or irreparable units must be disposed of in accordance with local waste disposal

### Special usage conditions

The widths and gaps of the flameproof joints of this apparatus are not identical with the respective minimum or maximum values required by Table 2 and 3 of IEC 60079-1:2014. Information on the dimensions are to be obtained from the manufacturer. Access to the enclosure is prevented by adhesion. Repair works of the enclosure and thus of the parts forming the flameproof joint can only be carried out by the manufacturer. The instructions contain relevant hints.

### **EU-Declaration of Conformity**

The product meets the requirements of the following standards and directives: EN IEC 60079-0:2018, IEC 60079-1:2014, IEC 60079-15:2010, IEC 60079-28:2015, IEC 60079-31:2013, EN 60529:2014, EN 61000-4-2 to EN 61000-4-6, EN 61000-6-1/-2, EN 61000-6-4, ATEX directive 2014/34/EU, Machine directive 2006/42/EC, EMC directive 2014/30/EU, RoHS directive

ATEX/IECEx-Designation:

Gas: II 2(1)G Ex db [op is Ga] IIC T6 Gb
Dust: II 2(1)D Ex db [op is Da] IIIC T100°C Db
ATEX EU-type examination certificate No.: BVS 10 ATEX E 130 X

IECEx CoC No.: IECEx BVS 14.0108X

Ex CB IECEx: DEKRA Testing and Certification GmbH, Carl-Beyling-Haus, Dinendahlstrasse 9, D-44809 Bochum, Ident number: 0158.

ATEX certification of quality management system, type production of Ex devices, in accordance

to the directive 2014/34/EU: Certification No.: SEV 21 ATEX 4580, QAR No.: CH/SEV/QAR21.0009/01, CB: Eurofins Electric & Electronic Product Testing AG, Luppmenstrasse 3, CH-8320 Fehraltorf CE 1258.

Pablo Ledergerber, Matrix Elektronik AG, is authorized to generation of documentation.

The conformity of the devices with all used standards and directives and the EC-type examination certificate and the observation of the Quality Management System ISO 9001:2015, de-

Ehrendingen, 11.6.2024

Pablo Ledergerber, Matrix Elektronik AG

Matrix Elektronik AG (Manufacturer) Kirchweg 24, CH-5420 Ehrendingen Tel.: +41 56 20400-20, Fax -29 info@matrix-elektronik.com