



Original Operating Manual:

Light Barriers series LBS/LBN/LBD-235-SHS/SDI/EHS(-OP)-SIL2 LBN-235-SHS/SDI/EHS-OP-SIL2

LBD-235-SHS/SDI/EHS-OP-SIL2







IECEx marking Ex d [op is Ga] IIC T6 Gb

Housing M18

High penetration capacity in polluted areas.

Optimal alignment by status visualization trough receiver optic

Series LBD: ATEX and IECEx certified

• LBD: For use in Ex zones (0), 1, 2, (20), 21, 22 optical radiation can operate into Ex Zones 0, 20

LBN: For use in Ex zones 2, 22

II 3G Ex nA op is IIB T4 Go Robust light barrier for industrial applications

Il 2(1)D Ex tb [op is Da] IIIB T100°C Db IP67 Robust light barrier for industrial applications II 30 Ex th [op is Da] IIIB T100°C Db IP67 II 30 Ex tb [op is Da] IIIB T100°C Db IP67			
Type designation emitter, standard	LBS-235-SHS-SIL2		LBD-235-SHS-OP-SIL2
Type designation emitter, with disable input "DI"			LBD-235-SDI-OP-SIL2
Technical Data Type designation receiver	LBS-235-EHS-SIL2		LBD-235-EHS-OP-SIL2
Type of Ex protection Gas, according to 2014/34/EU	NONE	II 3G Ex nA op is IIB T4 Go	II 2(1)G Ex d [op is Ga] IIC T6 Gb
Type of Ex protection Dust, according to 2014/34/EU	NONE	II 3D Ex tc op is IIIA T135°C Dc IP67	II 2(1)D Ex tb [op is Da] IIIB T100°C Db IP67
For use in Ex zones	NONE	Zones 2, 22	Zones (0), 1, 2, (20), 21, 22
Performance Level (PL)	PL C, according to EN 13849-1		
Safety Integrity Level (SIL)	SIL 2, according to EN 61508		
Mean probability of a dangerous failure per hour PFHd	2.06 x 10 ⁻⁶ , at 13849-1 (without PELV power supply)		
Sensing range	120m		
Minimum detectable object size	12mm (avoid mirror effects)		
Light source Maximum radiant intensity	NOT LIMITED	Infrared 870nm <=5mWm ²	<=5mWm²
Maximum radiant power	NOT LIMITED	< 35mW	< 15mW
Optical angle of aperture (at a distance of 10m)	NOT ENVITED	Emitter: appr.30° / Receive	
Response time	5ms (Switch off time)		
Power up delay time	300ms		
Supply voltage	24 VDC +-10% (Power supply type PELV at EN 60204, item 6.4.2)		
Absolute maximum supply voltage Um	30VDC		
Current consumption, emitter Current consumption, receiver	60mA 40mA		
Maximum power dissipation	40MA Emitter: max. 1.6W / Receiver: 1.1W		
Output	PNP type, double guided, 100mA, short circuit protected		
Permissible line resistance between device and load	10R		
Pollution indication output "VA"	PNP type, single guided, 100mA, short circuit protected		
Emitter disable (test) input SDI, optional	PNP compatible		
Housing	M18, brass Ms 58, nickel plated		
Enclosure rating, in accordance with EN 60529 Ambient working temperature range Tamb	IP 65 IP 67 IP67 0°C up to +50°C		
Storage temperature range	-20°C +70°C		
Relative humidity	15% 90%, noncondensing		
Vibration and shock resistance	Vibration: 30g over 20Hz to 2kHz. Shock: 100g for 3ms		
Pollution degree, in accordance with EN 60664-1:2007	4		
Device designation, in accordance with EN 60947-5-2	LBS/LBN/LBD-235-***(-OP)-SIL2: T3A30BP1 / LBS/LBN-235-***(-OP)-SIL2S099: T3A30BP2		
Connection cable	TPU insulation, AWM 20236, 2/3/4+PE x 0.5mm ² , shielded, leads numbering marked, oil resistant cable for trailing, length: 10m		
Socket M12, only types LBS/LBN-235-(OP)-SIL2-S099	Socket , Lumberg RSFM 5, 5 pins		
Accessories, all types, included	- 4x nuts M18 (or optional 2x clamps, on request)		
Accessories, only LBN-235-***-SIL2-S099, included	- 1x Safety lock device, mount at the cable connection, for locking the connection.		
	- 1x Warning plate "Do not open/close when supply voltage connected",		
	self-sealing, for gluing on the cable connector.		
Accessories only I DN 225 *** CII 2 C000 not included	 1x Protection cap for the sensor socket. Single ended cordset, types RKTS 5-298/xx or RKWTH 5-298/xx, Lumberg 		
Accessories, only LBN-235-***-SIL2-S099, not included Options	- LBS/LBN/LBD-235-***(-OP)-SIL2- S094 : Lenses special luted		
Options	- LBS/LBN-235-***(-OP)-SIL2- S099 : With socket M12, 5 pins		
	- LBS/LBN/LBD-235-		er with disable input DI
	- Cable length:	,	100m, on request
LED display and			
output function			
	Light beam		Light beam free
	LED's sh		D's shows yellow or green
Output function and wiring diagram (cable):			○+24VDC
Receiver: Emitter:	Channel 1	Chan	PNP=ON
1: $= +24VDC$ 1: $= +24VDC$	Channel	PNP=OFF Chang	PINE ON
2: = 0V 2: = 0V		'	$-\mathcal{O}$
3: = Output 3: = SDI, optional		,	
4: = Pollution indication output "VA"	Channel 2	PNP=OFF Change	nel2 (PNP=ON
(Cable shields, connect to PE)			<u> </u>
For connector types, see on page 2 of this operating		Output	Output
manual		ov	
Function pollution indication output "VA"	Output VA = 0V (LED's shows red) Output VA =24V if LED's shows yellow		
Alignment and controlling by LED display		am interrupted / not aligned	
(Status visualization trough receiver optic and LED at the	LED yellow: Polluted		. anough the contact
rearside of the receiver)	LED green: Light be	am free / well aligne	d lens

EX related markings

CE 0158

Types LBD:

Types LBN: Types LBD:

Types LBD:

Types LBN:


Exd[opisGa]IICT6Gb, II 3G Ex nA op is IIB T4 Gc, ATEX certification

ATEX declaration by manufacturer

IECEx certification

Manufacturer with address

(X designation of the certification number: Fibre optics must only be used with sensors with certificated limited optical power)



Operating Manual, EU - Declaration of Conformity:

The barrier is a non-separating protective device at machinery directive 2006/42/EC. It must not be possible to start the machinery/system as long as personnel are within the hazardous area. The double guided output is only switched ON, when the light beam is not interrupted. The light barriers are composed of an emitter and a receiver device only of the same type. The types must not be mixed. The light barriers must only be operated with post-switched emergency-stop devices or programmable safety devices. All relevant standards and directives for the complete system or machinery, for performance level Plc, at EN ISO 13849-1, must be observed. The applicant is responsible to realize a restart interlock at the machinery if requisite. This can be realized with a with an external equipment. All warranty claims against Matrix Elektronik AG are forfeited in the case of any other use, or alterations being made General prescriptions for all Ex devices:

It is necessary to take into consideration the valid international and national

rules and regulations (EN 60079-14). The maximum input voltage Um=30VDC must not be exceeded. The local equipotential bonding have to be done. The protective earth (PE) terminal is solid connected with the housing. The cable have to be protected against damages. The cable with termination fittings, or in cable tray systems and installed in a manner to avoid tensile stress at the termination fittings. To connect cables inside hazardous locations only use certificated Ex housings. All cable terminals must be connected outside hazardous locations. Use only original manufactured fibre optics and additional optical lenses, other additional optical lenses

are not allowed in hazardous locations.

Emitter: LBD-235-SHS/SDI-OP-SIL2, Receiver: LBD-235-EHS-OP-SIL2:
Applicable in Ex zones 1, 2, 21, 22. The limited optical radiation can operate into hazardous locations 0 or 20 over certificated fibre optics or through a viewing glass.
Emitter: LBN-235-SHS/SDI-OP-SIL2, Receiver: LBN-235-EHS-OP-SIL2:

Applicable only in Ex zones 2, 22.

Emitter: LBN-235-SHS/SDI-OP-SIL2-S099, Receiver: LBN-235-EHS-OP-SIL2-S099: Applicable only in Ex zones 2, 22. WARNING! Do not contain the complex of the cable. Separate the connector when the supply voltage is connected to the cable. When installing the sensor, the safety lock device must be fitted at the cable connector. The additional adhesive warning label must be fixed to the connector housing at the connection cable. Lumberg cordsets RKTS -298/xx (Straight type) or RKWTH 5-298/xx (Right angle type) are allowed ONLY. It is necessary to take into consideration the mounting prescription of the connector manufacturer. In dusty locations, the socket protection cap must be fitted, when the connection cable is not connected.

General mounting prescriptions:

Do not exceed the maximum ratings. The electrical connections must be exactly as shown in the connection diagram. The cable shield must be connected short. The cable shield should be connected to the earth, large-surfaced. Connection cables must not be installed parallel to high voltage cables.

Function

If the light beam is not interrupted the output switches to ON (+24V). If the light beam is interrupted the output switches to OFF. (The output is built by 2 different PNP transistors, wired in series). The light barrier LBxbuilt by 2 different PNP transistors, when in series). The light barrier Lbx-235 works with two different light sources, visible red light and infrared. The high density and the two different wavelengths gives a high penetration capacity at a heavy polluted ambiance. The load (Relay or other loads) must be connected at "-" (minus). Because the emitters has a very high optical power, it's to avoid mirroring effects at the background, when not all receivers are located at the same side.

Pollution indication output "VA"

The VA output will be activated by polluted lenses or a bad alignment. If the lenses are polluted, the LED shows yellow and the VA output switches to ON (+24V). This function gives the possibility to recognize pollutions

Arrangement of light barriers, types LB*-235-SDI(-OP)-SIL2 (optional): If several light barriers are installed close to another, it is necessary

to use light barriers with emitters with disable input. By using the disable input DI, each emitter can be controlled in a short reaction time. If only one emitter is activated in the same time, a mutual influence is precluded.

0V or not connected = emitter enabled High (24VDC) = emitter disabled

The Disable Input SDI must be activated for >= 15ms. The SDI input is PNP compatible. The Emitter-Disable-Input DI can also be used for testing the associated receiver. By a short-time shut-off of the emitter, off of the receiver output and with it the correct function of the receiver will

Alignment of the Light Barrier:

The three color indication in the receiver optic allows an optimal alignment. 1. The emitter must be aligned this way, that the emitter lens is fully illuminated (By watching from the receiver at the emitter).

2. The receiver should be moved, until the LED (from the receiver) shows "green". Search the middle of the green range.

Maintenance:

No special maintenance is required. If the lenses becomes dirty, they should be cleaned with a non-aggressive solvents. Equipment must only be repaired

by the manufacturer.

General safety instructions:

The operating manual provide the machine manufacturer's or machine operator's technical personnel instructions on the safe mounting, configuration, electrical installation, commissioning, and on the operation and maintenance of the light barrier. Please read the operating instructions maintenance of the light barrier. Please read the operating instructions carefully. Types: LBN-235-SHS/SDI-OP-SIL2-S099, LBN-235-EHS-OP-SIL2-S099: "WARNING - EXPLOSION HAZARD - WHEN IN HAZARD-OUS LOCATIONS, TURN OFF POWER BEFORE REPLACING OR WIRING MODULES. DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS". The mounting of the sensor in dusty locations without fixed cordset or protection cap results in a high ignition risk. In worst case of breakdown, the output can change to any state! When installing and operating with the sensor, it is necessary to take into consideration the relevant international and other national regulations: EN 60079-14, ATEX 118a. single directive 1999/92/EC. The sensors are conform to the ATEX 118a, single directive 1999/92/EC. The sensors are conform to the following standards:

IEC/EN 60079-0:2012 + A11:2013, IEC/EN 60079-1:2007, EN 60079-15:2010, IEC/EN 60079-28:2007, IEC/EN 60079-31:2010, EN 13849-1:2008, 15:2010, IEC/EN 60079-28:2007, IEC/EN 60079-31:2010, EN 13849-1:2008, EN 61508-3:2010, EN 61326-3:2008, EN 60204-1:2005, EN 60529:2014, EN 60950-1:2006; EN 61000-4-2 to EN 61000-4-6, EN 61000-6-1/-2, EN 61000-6-4, ATEX directive: 2014/34/EU, Machine directive: 2006/42/EC, EMC directive: 2014/30/EU, RoHS directive: 2011/65/EU.

General Notes, disposal:

We reserve the right to modify our equipment. Our equipment is designed such way, that it has the least possible adverse effect on the environment. It neither emit or contain any damaging or siliconized substances and use a minimum of energy and resources. No longer usable or irreparable units must be disposed of in accordance with local waste disposal regulations.

EU-Declaration of conformity:

IECEx certification, types LBD: Ex d [op is Ga] IIC T6 Gb, Ex tb [op is Da]

IIIB T100°C Db IP67. Certification No. IECEx BVS 14.0108X.

http://iecex.iec.ch/iecex/iecexweb.nsf/0/FE79714C0BAEF6F5C1257D7E0044F6A9?opendocument http://ecex.lecc./viecex/ecexweb.ns/IOFE78714C0BAEF6F5C1257D7E0044F6A9?opendocument
ATEX certification, types LBD: II 2(1)G Ex d [op is Ga] IIC T6 Gb, II 2(1)D
Ex tb [op is Da] IIIB T100°C Db IP67. Certification No. BVS 10 ATEX E 130
X, DEKRA EXAM GmbH, Zertifizierungsstelle, Carl-Beyling-Haus,
Dinendahlstrasse 9, D-44809 Bochum, Kennnummer: 0158.
ATEX certification, types LBN: II 3G Ex d op is IIB T4 Gc, II 3D Ex tc op
is IIIA T135°C Dc IP67. ATEX declaration by manufacturer in accordance
to the ATEX directive 2014/34/EU. ATEX certification of quality type

production of Ex devices in accordance to the directive 2014/34/EU, CE 0158. Certification No: BVS 12 ATEX ZQS / E118. The conformity of the devices with the EC standards and directives and the EC-type examination certificate and the observation of the Quality Safety System ISO 9001:2008 with the ATEX module "Production", declares:

Hans Bracher, Matrix Elektronik AG

Meegener Str. 43 D-51491 Overath Tel.:+49 2206 9566-0 Fax -19

nfo@tippkemper-matrix.com

-29 Kirchweg 24 CH-5420 Ehrendingen Tel.:+41 56 20400-20 Fax -2 info@matrix-elektronik.com Elektronik AG (

Page 2 of 2